

## Detailed Maintenance Steps:

### 1. Regular Cleaning:

**Clean the tracks:** Vacuum the tracks to remove loose dirt and debris, then wash them with warm soapy water and a soft brush or cloth.

**Clean the frame:** Wash the aluminium frame with warm soapy water and a soft cloth. Avoid abrasive cleaners that can scratch the finish.

**Clean the glass:** Use a glass cleaner and a soft cloth to clean the glass panels.

### 2. Lubrication:

**Identify moving parts:** The tracks and rollers are the main areas that need lubrication.

**Use a silicone-based lubricant:** Apply a silicone-based lubricant to the tracks and rollers, ensuring it penetrates the moving parts.

**Work the door:** Open and close the door several times to distribute the lubricant evenly.

### 3. Inspection:

**Check for wear and tear:** Regularly inspect the tracks, rollers, and other moving parts for signs of wear or damage.

**Look for misalignment:** Ensure the door is properly aligned and doesn't stick or rub against the frame.

**Address issues promptly:** If you notice any problems, address them promptly to prevent further damage or issues